

Model 2000 Mist Collector

Model # SS-2000-MIST

Product Specifications

BASE UNIT DIMENSIONS

45" Length
24" Width
24" Height

OUTLET CONFIGURATION

Four-Way Adjustable Grill

CABINET MATERIAL

16 ga. Carbon Steel with Polyester Powder Coating

WEIGHT

Approx. 124 lbs.

AIR VOLUME

Up to 2000 CFM (High)

ELECTRICAL

208-230/1/60, 5.6 amps

SOUND LEVEL

70dba (High) at 6'

FILTRATION

(4) Cleanable Mesh Pre-Filters
(1) Oil Mist Bag Filter

WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.



Dimensions are Approximate



Product Features

- Four-Way Adjustable Grill
- Low Power Consumption
- Simple, Quick "No Tool" Filter Change
- Quiet Operation
- Reliable, Low Maintenance Operation
- Long Filter Life

The **Model 2000 Ambient Mist Collector** is designed to capture and collect excess mist commonly found in machining and tooling shops. Air is pulled through four mesh pre-filters then into a main filter bag specially-designed to handle mist and other wet environments. Any remaining mist is collected and drained through a plug at the base of the unit.

Typical applications include general shop mist collection, open CNC lathes and waterjet machines that produce ambient mist, and other applications that produce oil mist, water mist or coolant mist.

A popular installation method is hanging the Model 2000 from a ceiling. Alternative options include mounting to our Fume Extractor Stand, placing the unit on a cart or table, or mounting to a wall shelf. Depending on the size of your work area, you may want to consider installing more than one Model 2000 to better cleanse the air and create optimal airflow patterns.

This unit underwent stringent third-party testing and evaluation to verify that all internal components are able to withstand a moist environment.

Unique to our standard Mist Collector catalog, the Model 2000 Ambient Mist Collector is ideal for environments where direct-mounting a mist collection system is not available or feasible.



1.800.799.4609
www.sentryair.com
sales@sentryair.com

